

## OM 109L/16 K Cat. 2024 Garden tractor



### Документы

Mulching Kit

Mowing deck

Engine

Tank

Transmission

Frame

Front axle

Steering arm

Rear axle

Seat


Cutting plate lifting

Electrical parts


Body

Towing hitch

Labels



| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 3      | 1   | TS000043R   | Hook        |               |               |       |          |
| 4      | 1   | TS000044R   | Tie rod     |               |               |       |          |
| 6      | 1   | TS000046R   | Deflector   |               |               |       |          |




изображение Mowing deck

| Ref.Nu | Qty | Part number | Description           | Validity from | Validity till | Notes                      | Bulletin      |
|--------|-----|-------------|-----------------------|---------------|---------------|----------------------------|---------------|
| 1      | 1   | TS000115R   | Right guard           |               |               |                            |               |
| 4      | 5   | TS000066R   | Clamp                 |               |               |                            |               |
| 7      | 1   | TS000116R   | Pin                   |               |               |                            |               |
| 8      | 1   | TS000117R   | Spring                |               |               |                            |               |
| 9      | 2   | TS000071R   | Screw                 |               |               |                            |               |
| 10     | 2   | TS000074R   | Wheel                 |               |               |                            |               |
| 12     | 1   | TS000118R   | Mount                 |               |               |                            |               |
| 14     | 1   | TS000119R   | Belt cover            |               |               |                            |               |
| 16     | 1   | TS000120R   | Bushing               |               |               |                            |               |
| 17     | 2   | TS000090R   | Water hose connection |               |               |                            |               |
| 20     | 1   | TS000121R   | Lever                 |               |               |                            | BT8-023-01/25 |
| 21     | 1   | TS000122R   | Bushing               |               |               |                            | BT8-023-01/25 |
| 22     | 1   | TS000007R   | Pulley                |               |               |                            | BT8-023-01/25 |
| 24     | 1   | TS000143R   | V belt                |               |               |                            |               |
| 25     | 1   | TS000124R   | Bracket               |               |               |                            |               |
| 27     | 1   | TS000125R   | Left guard            |               |               |                            |               |
| 28     | 1   | TS000126R   | Pulley                |               |               |                            | BT8-023-01/25 |
| 29     | 1   | TS000127R   | Bushing               |               |               |                            | BT8-023-01/25 |
| 32     | 1   | TS000128R   | Belt cover            |               |               |                            |               |
| 33     | 1   | TS000129R   | Spacer                |               |               |                            | BT8-023-01/25 |
| 34     | 1   | TS000130R   | Spring                |               |               |                            |               |
| 35     | 1   | TS000065R   | Screw                 |               |               |                            |               |
| 37     | 1   | TS000144R   | Mowing deck           |               |               |                            | BT8-023-01/25 |
| 40     | 1   | TS000145R   | Bracket               |               |               |                            |               |
| 41     | 2   | TS000132R   | Nut                   |               |               |                            |               |
| 42     | 2   | TS000111R   | Pulley                |               |               |                            |               |
| 43     | 2   | TS000082R   | Key                   |               |               |                            |               |
| 44     | 2   | TS000133R   | Blade shaft           |               |               |                            |               |
| 45     | 2   | TS000085R   | Disc (guard)          |               |               |                            |               |
| 46     | 4   | TS000086R   | Bearing               |               |               |                            |               |
| 47     | 2   | TS000134R   | Support               |               |               |                            |               |
| 49     | 2   | TS000135R   | Guard                 |               |               |                            |               |
| 50     | 2   | TS000099R   | Key                   |               |               |                            |               |
| 51     | 2   | TS000095R   | Blade hub             |               |               | Acquistare anche il codice |               |
| 52     | 2   | TS000136R   | Pin                   |               |               |                            |               |
| 55     | 2   | TS000091R   | Plate                 |               |               |                            |               |
| 57     | 2   | TS000146R   | Blade                 |               |               |                            |               |
| 58     | 2   | TS000097R   | Washer                |               |               |                            |               |
| 60     | 2   | TS000098R   | Screw                 |               |               |                            |               |
| 63     | 1   | TS000138R   | Pin                   |               |               |                            |               |
| 64     | 1   | TS000139R   | Spring                |               |               |                            |               |
| 65     | 1   | TS000140R   | Locking lever         |               |               |                            |               |
| 66     | 1   | TS000141R   | Lever support         |               |               |                            |               |
| 67     | 1   | TS000142R   | Deflector             |               |               |                            |               |

изображение Mowing deck


| Ref.Nu | Qty | Part number | Description            | Validity from | Validity till | Notes | Bulletin      |
|--------|-----|-------------|------------------------|---------------|---------------|-------|---------------|
| 68     | 1   | TS000429R   | Cutting plate assembly |               |               |       | BT8-023-01/25 |



изображение Engine


| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes                   | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------------------------|----------|
| 1      | 1   | TS000147R   | Knob           |               |               |                         |          |
| 4      | 1   | TS000008R   | Throttle cable |               |               |                         |          |
| 7      | 1   | TS000009R   | Key            |               |               |                         |          |
| 8      | 1   | TS000148R   | Pulley         |               |               | Motore 12,5 KM - Engine |          |
| 8      | 1   | TS000159R   | Pulley         |               |               | Motore 14,5 K / 16 K -  |          |
| 9      | 1   | TS000010R   | Support        |               |               | Engine 14,5 K / 16 K    |          |
| 11     | 1   | TS000149R   | Clutch         |               |               |                         |          |
| 12     | 1   | TS000150R   | Bushing        |               |               |                         |          |
| 13     | 1   | TS000151R   | Thickness      |               |               |                         |          |
| 14     | 1   | TS000152R   | Bolt           |               |               |                         |          |
| 15     | 1   | TS000153R   | Plate          |               |               |                         |          |
| 17     | 1   | TS000154R   | Bracket        |               |               | Motore 12,5 KM - Engine |          |
| 17     | 1   | TS000160R   | Bracket        |               |               | Motore 14,5 K / 16 K -  |          |
| 19     | 1   | TS000155R   | Exhaust pipe   |               |               | Engine 14,5 K / 16 K    |          |
| 23     | 1   | TS000156R   | Gasket         |               |               |                         |          |
| 24     | 1   | TS000157R   | Muffler        |               |               |                         |          |
| 25     | 1   | TS000158R   | Support        |               |               |                         |          |
| 29     | 1   | TS000011R   | Grid           |               |               |                         |          |






изображение Tank

| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 10     | 1   | TS000012R   | Filter      |               |               |       |          |
| 11     | 1   | TS000161R   | Tank        |               |               |       |          |
| 13     | 1   | TS000162R   | Band        |               |               |       |          |
| 14     | 1   | TS000163R   | Fuel hose   |               |               |       |          |
| 15     | 1   | TS000164R   | Band        |               |               |       |          |
| 16     | 1   | TS000013R   | Tank cap    |               |               |       |          |




изображение Transmission

| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 2      | 2   | TS000173R   | Bushing     |               |               |       |          |
| 3      | 1   | TS000253R   | Spacer      |               |               |       |          |
| 5      | 1   | TS000255R   | Support     |               |               |       |          |
| 6      | 1   | TS000130R   | Spring      |               |               |       |          |
| 8      | 1   | TS000122R   | Bushing     |               |               |       |          |
| 9      | 1   | TS000007R   | Pulley      |               |               |       |          |
| 11     | 1   | TS000006R   | Pulley      |               |               |       |          |
| 12     | 1   | TS000005R   | Bearing     |               |               |       |          |
| 16     | 1   | TS000263R   | Plate       |               |               |       |          |
| 20     | 1   | TS000259R   | Screw       |               |               |       |          |
| 21     | 1   | TS000025R   | Belt        |               |               |       |          |
| 23     | 3   | TS000023R   | Pulley      |               |               |       |          |
| 24     | 2   | TS000260R   | Bushing     |               |               |       |          |
| 25     | 1   | TS000265R   | Rod support |               |               |       |          |
| 26     | 1   | TS000266R   | Rod         |               |               |       |          |



изображение Frame


| Ref.Nu | Qty | Part number | Description             | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------------------|---------------|---------------|-------|----------|
| 2      | 1   | TS000165R   | Right footboard support |               |               |       |          |
| 4      | 1   | TS000166R   | Footrest pad            |               |               |       |          |
| 5      | 2   | TS000167R   | Right footboard cover   |               |               |       |          |
| 8      | 1   | TS000168R   | Right footboard support |               |               |       |          |
| 10     | 1   | TS000169R   | Bushing                 |               |               |       |          |
| 12     | 1   | TS000170R   | Frame                   |               |               |       |          |
| 13     | 1   | TS000171R   | Hood support RX         |               |               |       |          |
| 14     | 1   | TS000172R   | Support                 |               |               |       |          |
| 15     | 1   | TS000014R   | Washer                  |               |               |       |          |
| 16     | 2   | TS000015R   | Bumper                  |               |               |       |          |
| 17     | 1   | TS000173R   | Bushing                 |               |               |       |          |
| 18     | 1   | TS000016R   | Bumper                  |               |               |       |          |
| 19     | 1   | TS000017R   | Lower hood              |               |               |       |          |
| 22     | 2   | TS000174R   | Support                 |               |               |       |          |
| 23     | 1   | TS000175R   | Support                 |               |               |       |          |
| 25     | 2   | TS000176R   | Plate                   |               |               |       |          |
| 26     | 1   | TS000177R   | Column support          |               |               |       |          |
| 28     | 1   | TS000178R   | Left footboard support  |               |               |       |          |
| 29     | 1   | TS000179R   | Footrest pad            |               |               |       |          |
| 30     | 1   | TS000180R   | Left footboard cover    |               |               |       |          |
| 31     | 1   | TS000181R   | Frame                   |               |               |       |          |
| 32     | 2   | TS000182R   | Seat support            |               |               |       |          |
| 33     | 2   | TS000183R   | Left footboard support  |               |               |       |          |



изображение Front axle


| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|-------|----------|
| 1      | 2   | TS000198R   | Hub cap        |               |               |       |          |
| 3      | 2   | TS000199R   | Washer         |               |               |       |          |
| 4      | 4   | TS000200R   | Spacer         |               |               |       |          |
| 5      | 2   | TS000018R   | Complete wheel |               |               |       |          |
| 5,4    | 4   | TS000204R   | Bearing        |               |               |       |          |
| 6      | 1   | TS000019R   | Pin            |               |               |       |          |
| 8      | 4   | TS000020R   | Bushing        |               |               |       |          |
| 9      | 1   | TS000205R   | Front axle     |               |               |       |          |
| 11     | 1   | TS000021R   | Lever          |               |               |       |          |
| 12     | 2   | TS000083R   | Washer         |               |               |       |          |
| 17     | 1   | TS000206R   | Spacer         |               |               |       |          |
| 18     | 2   | TS000068R   | Nipple         |               |               |       |          |
| 21     | 1   | TS000022R   | Pin            |               |               |       |          |






изображение Steering arm

| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes            | Bulletin |
|--------|-----|-------------|----------------|---------------|---------------|------------------|----------|
| 1      | 1   | TS000267R   | Angle joint    |               |               |                  |          |
| 3      | 1   | TS000268R   | Tie rod        |               |               |                  |          |
| 5      | 1   | TS000269R   | Plate          |               |               |                  |          |
| 8      | 1   | TS000270R   | Sleeve         |               |               |                  |          |
| 9      | 1   | TS000271R   | Bushing        |               |               |                  |          |
| 10     | 1   | TS000272R   | Snap ring      |               |               |                  |          |
| 11     | 1   | TS000273R   | Steering arm   |               |               |                  |          |
| 13     | 2   | TS000274R   | Bushing        |               |               |                  |          |
| 14     | 1   | TS000275R   | Tie rod        |               |               |                  |          |
| 16     | 1   | TS000026R   | Sprocket       |               |               |                  |          |
| 17     | 1   | TS000276R   | Pin            |               |               |                  |          |
| 19     | 1   | TS000378R   | Bushing        |               |               |                  |          |
| 20     | 1   | TS000277R   | Bushing        |               |               |                  |          |
| 21     | 1   | TS000278R   | Cotter pin     |               |               |                  |          |
| 22     | 1   | TS000279R   | Fixing plate   |               |               |                  |          |
| 23     | 2   | TS000280R   | Bushing        |               |               |                  |          |
| 24     | 1   | TS000027R   | Sector         |               |               |                  |          |
| 25     | 1   | TS000281R   | Fixing plate   |               |               |                  |          |
| 26     | 1   | TS000282R   | Angle joint    |               |               |                  |          |
| 28     | 1   | TS000283R   | Spacer         |               |               |                  |          |
| 30     | 1   | TS000284R   | Steering wheel |               |               |                  |          |
| 31     | 1   | TS000028R   | Support        |               |               |                  |          |
| 32     | 1   | TS000379R   | Washer         |               |               |                  |          |
| 33     | 1   | TS000376R   | Cover          |               |               | Arancio - Orange |          |




изображение Rear axle

| Ref.Nu | Qty | Part number | Description       | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------------|---------------|---------------|-------|----------|
| 1      | 2   | TS000198R   | Hub cap           |               |               |       |          |
| 2      | 2   | TS000207R   | Snap ring         |               |               |       |          |
| 3      | 4   | TS000199R   | Washer            |               |               |       |          |
| 4      | 2   | TS000212R   | Complete wheel    |               |               |       |          |
| 5      | 2   | TS000210R   | Key               |               |               |       |          |
| 8      | 1   | TS000240R   | Plate             |               |               |       |          |
| 10     | 1   | TS000241R   | Transmission      |               |               |       |          |
| 11     | 1   | TS000242R   | Pin               |               |               |       |          |
| 15     | 1   | TS000243R   | Support           |               |               |       |          |
| 17     | 1   | TS000244R   | Brake cable       |               |               |       |          |
| 18     | 1   | TS000245R   | Clamp cover rear  |               |               |       |          |
| 19     | 1   | TS000246R   | Pedal             |               |               |       |          |
| 23     | 1   | TS000247R   | Pin               |               |               |       |          |
| 25     | 1   | TS000248R   | Tie rod           |               |               |       |          |
| 27     | 1   | TS000249R   | Plate             |               |               |       |          |
| 29     | 1   | TS000250R   | Spring            |               |               |       |          |
| 30     | 2   | TS000231R   | Support           |               |               |       |          |
| 32     | 1   | TS000230R   | Support           |               |               |       |          |
| 33     | 1   | TS000251R   | Clamp cover front |               |               |       |          |
| 37     | 1   | TS000232R   | Bushing           |               |               |       |          |
| 38     | 1   | TS000233R   | Control           |               |               |       |          |
| 40     | 1   | TS000234R   | Control rod       |               |               |       |          |
| 41     | 1   | TS000235R   | Handle            |               |               |       |          |
| 42     | 1   | TS000236R   | Fork              |               |               |       |          |
| 43     | 1   | TS000237R   | Spring            |               |               |       |          |
| 44     | 1   | TS000238R   | Pedal             |               |               |       |          |
| 45     | 1   | TS000239R   | Cover moulding    |               |               |       |          |



изображение Seat


| Ref.Nu | Qty | Part number | Description  | Validity from | Validity till | Notes            | Bulletin |
|--------|-----|-------------|--------------|---------------|---------------|------------------|----------|
| 2      | 1   | TS000285R   | Support      |               |               |                  |          |
| 4      | 2   | TS000286R   | Spring       |               |               |                  |          |
| 7      | 2   | TS000287R   | Cover        |               |               |                  |          |
| 8      | 1   | TS000288R   | Seat support |               |               |                  |          |
| 9      | 2   | TS000289R   | Screw        |               |               |                  |          |
| 10     | 2   | TS000290R   | Slide        |               |               |                  |          |
| 12     | 1   | TS000029R   | Seat switch  |               |               |                  |          |
| 13     | 1   | TS000373R   | Seat         |               |               | Arancio - orange |          |
| 14     | 4   | TS000291R   | Spacer       |               |               |                  |          |



изображение Cutting plate lifting


| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|-------|----------|
| 3      | 2   | TS000313R   | Rod         |               |               |       |          |
| 4      | 1   | TS000293R   | Tie rod     |               |               |       |          |
| 6      | 1   | TS000294R   | Angle joint |               |               |       |          |
| 10     | 1   | TS000308R   | Rod         |               |               |       |          |
| 11     | 1   | TS000309R   | Axle        |               |               |       |          |
| 12     | 1   | TS000297R   | Rod         |               |               |       |          |
| 13     | 1   | TS000298R   | Support     |               |               |       |          |
| 15     | 4   | TS000231R   | Support     |               |               |       |          |
| 16     | 3   | TS000299R   | Angle joint |               |               |       |          |
| 17     | 1   | TS000310R   | Lever       |               |               |       |          |
| 19     | 1   | TS000301R   | Plate       |               |               |       |          |
| 20     | 1   | TS000226R   | Knob        |               |               |       |          |
| 21     | 1   | TS000030R   | Support     |               |               |       |          |
| 22     | 1   | TS000302R   | Spring      |               |               |       |          |
| 25     | 1   | TS000303R   | Spring      |               |               |       |          |
| 26     | 1   | TS000031R   | Lever       |               |               |       |          |
| 27     | 1   | TS000223R   | Snap ring   |               |               |       |          |
| 28     | 2   | TS000378R   | Bushing     |               |               |       |          |
| 29     | 1   | TS000304R   | Lever group |               |               |       |          |
| 30     | 1   | TS000311R   | Tie rod     |               |               |       |          |
| 31     | 1   | TS000312R   | Tie rod     |               |               |       |          |






изображение Electrical parts

| Ref.Nu | Qty | Part number | Description       | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-------------------|---------------|---------------|-------|----------|
| 1      | 1   | TS000314R   | Cable             |               |               |       |          |
| 2      | 1   | TS000339R   | Wiring            |               |               |       |          |
| 3      | 20  | TS000316R   | Band              |               |               |       |          |
| 3      | 5   | TS000317R   | Band              |               |               |       |          |
| 4      | 1   | TS000318R   | Switch protection |               |               |       |          |
| 5      | 1   | TS000032R   | Switch            |               |               |       |          |
| 6      | 1   | TS000319R   | Cable             |               |               |       |          |
| 8      | 1   | TS000033R   | Solenoid          |               |               |       |          |
| 11     | 1   | TS000323R   | Clamp             |               |               |       |          |
| 13     | 1   | TS000324R   | Wire              |               |               |       |          |
| 14     | 1   | TS000325R   | Fuse              |               |               |       |          |
| 15     | 1   | TS000034R   | Switch            |               |               |       |          |
| 16     | 1   | TS000326R   | Switch            |               |               |       |          |
| 17     | 1   | TS000035R   | Shoe              |               |               |       |          |
| 19     | 1   | TS000332R   | Belt              |               |               |       |          |
| 20     | 1   | TS000038R   | Battery           |               |               |       |          |
| 21     | 2   | TS000333R   | Bracket           |               |               |       |          |
| 23     | 1   | TS000336R   | Control lever     |               |               |       |          |
| 24     | 1   | TS000331R   | Switch            |               |               |       |          |
| 27     | 1   | TS000337R   | Bracket           |               |               |       |          |
| 28     | 2   | TS000037R   | Micro-switch      |               |               |       |          |
| 31     | 1   | TS000338R   | Support           |               |               |       |          |
| 32     | 1   | 68130481    | Battery charger   |               |               |       |          |
| 33     | 1   | TS000412R   | Starting key      |               |               |       |          |




| Ref.Nu | Qty | Part number | Description  | Validity from | Validity till | Notes            | Bulletin |
|--------|-----|-------------|--------------|---------------|---------------|------------------|----------|
| 1      | 1   | TS000340R   | Wiring       |               |               |                  |          |
| 2      | 1   | TS000341R   | Adapter      |               |               |                  |          |
| 3      | 1   | TS000342R   | Deflector    |               |               |                  |          |
| 4      | 1   | TS000343R   | Right guard  |               |               |                  |          |
| 6      | 5   | TS000344R   | Fairled      |               |               |                  |          |
| 7      | 1   | TS000361R   | Right guard  |               |               | Arancio - orange |          |
| 10     | 2   | TS000345R   | Pin          |               |               |                  |          |
| 11     | 1   | TS000346R   | Headlamp     |               |               |                  |          |
| 12     | 1   | TS000364R   | Guard        |               |               | Arancio - orange |          |
| 13     | 1   | TS000039R   | Upper hood   |               |               |                  |          |
| 14     | 1   | TS000347R   | Headlamp     |               |               |                  |          |
| 15     | 1   | TS000367R   | Engine cover |               |               | Arancio - orange |          |
| 16     | 1   | TS000370R   | Left guard   |               |               | Arancio - orange |          |
| 17     | 1   | TS000348R   | Left guard   |               |               |                  |          |
| 19     | 1   | TS000349R   | Cover        |               |               |                  |          |
| 20     | 4   | TS000350R   | AV-mount     |               |               |                  |          |
| 22     | 1   | TS000351R   | Dashboard    |               |               |                  |          |
| 23     | 9   | TS000066R   | Clamp        |               |               |                  |          |
| 24     | 1   | TS000352R   | Panel        |               |               |                  |          |
| 25     | 1   | TS000040R   | Cover        |               |               |                  |          |
| 29     | 1   | TS000042R   | Cover        |               |               |                  |          |
| 30     | 1   | TS000356R   | Guard        |               |               |                  |          |
| 31     | 2   | TS000173R   | Bushing      |               |               |                  |          |
| 34     | 1   | TS000357R   | Lock         |               |               |                  |          |



изображение Towing hitch

| Ref.Nu | Qty | Part number | Description  | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|--------------|---------------|---------------|-------|----------|
| 2      | 1   | TS000358R   | Towing hitch |               |               |       |          |
| 3      | 2   | TS000359R   | Spacer       |               |               |       |          |



изображение Labels

| Ref.Nu | Qty | Part number | Description | Validity from | Validity till | Notes    | Bulletin |
|--------|-----|-------------|-------------|---------------|---------------|----------|----------|
| 1      | 1   | TS000406R   | Label       |               |               |          |          |
| 2      | 1   | TS000397R   | Label       |               |               |          |          |
| 3      | 1   | TS000389R   | Label       |               |               | 109L/16K |          |