





Model: ZERO 107E

Chair Part




N	ART	Name	QTY
1	ZT107-0001	Seat	1
2	U537-00111	Lock Bolt - M10	4
3	U455-00029	Washer - 10x2	8
4	ZT107-0002	Seat mounting plate	1
5	UZT85-00239	Shock absorber	2
6	ZT107-0003	Screw - M10x30	4
7	U537-00060	Bolt - M10x20	4
8	U455-00061	Washer - 8x1.6	8
9	U455-00007	Lock Nut - M8	4
10	ZT107-0004	Seat mounting plate	1

Model: ZERO 107E
Shell part



N	ART	Name	QTY
1	ZT107-0005	Display screen	1
2	UR760-00058	Key switch	1
3	UZT85-00154	Knife switch	1
4	ZT107-0006	Control panel	1
5	ZT107-0007	Screw	2
6	ZT107-0008	Power outlet	1
7	ZT107-0009	Rear cover	1
8	ZT107-0010	Upper guard cover	1
9	ZT107-0011	Left cover	1
10	ZT107-0012	Upper cover	1
11	ZT107-0013	Right cover	1
12	ZT107-0014	Screw	52
13	ZT107-0015	Shell layering	1
14	ZT107-0016	Nut - M6	15
15	ZT107-0017	Front cover	1
16	ZT107-0018	Rivet	4


Model: ZERO 107E
Engine Part



N	ART	Name	Quantity
1	ZT107-0019	Bolt - M8x180	4
2	U455-00053	Spring Washer - 8x2.1	4
3	U455-00061	Washer - 8x1.6	4
4	UR760-00038	Screw	2
5	ZT107-0020	fuse	1
6	ZT107-0021	Connector	1
7	ZT107-0022	Battery cover	1
8	UG700-00055	Bolt - M6x20	12
9	UG700-00056	Spring Washer - 6x1.6	12
10	U455-00054	Washer - 6x1.6	12
11	ZT107-0023	Wire harness	1
12	ZT107-0024	Positive sheath	6
13	ZT107-0025	Wire harness	4
14	ZT107-0026	Negative sheath	6
15	ZT107-0027	Wire harness	1
16	ZT107-0028	Battery	6
17	ZT107-0029	Battery tray	1
18	UA516-00001	Bearing	8
19	U506-00021		8
20	ZT107-0030	Wire harness	1
21	ZT107-0031	Wire harness	1
22	ZT107-0032	Charger	1
23	ZT107-0033	European standard charging cable	1
24	ZT107-0034	American standard charging cable	1
25	ZT107-0035	British standard charging cable	1
26	ZT107-0036	Australian standard charging cable	1

Model: ZERO 107E


Left handle part



N	ART	Name	Quantity
1	ZT107-0037	Left handle	1
2	UG806-00029	Bolt - M8x25	2
3	UR420-00008	Spring Washer - 8x2.4	5
4	U455-00061	Washer - 8x1.6	5
5	UG806-00029	Bolt - M8x25	2
6	UR200-00079	Nut - M3	2
7	ZT107-0038	Shaft presser	1
8	ZT107-0039	Damping pad	2
9	UV160-00024	Screw - M3x20	2
10	UR200-00080	Spring Washer - 3x0.6	2
11	UV160-00036	Washer - 3x0.5	4
12	ZT107-0040	Pressure plate	1
13	ZT107-0041	Switch	1
14	ZT107-0042	Mounting plate	1
15	UG390-00064	Bolt - M8x55	1
16	UG700-00022	Nut - M8	2
17	UG390-00064	Bolt - M8x55	1
18	ZT107-0043	Shaft	1
19	ZT107-0044	Electronic throttle	1
20	ZT107-0045	Mounting plate	1
21	UZT85-00135	Washer - 4x0.5	2
22	ZT107-0046	Spring Washer - 4x1.1	4
23	ZT107-0047	Bolt - M5x35	2
24	ZT107-0048	Handle return	1
25	UG700-00056	Spring Washer - 6x1.3	2
26	ZT107-0049	Bolt - M6x16	2
27	ZT107-0050	Lock Nut - M8	1
28	ZT107-0051	Hinge	1
29	ZT107-0052	Damping pad	1
30	ZT107-0053	Gasket	2
31	ZT107-0054	Connector	1
32	ZT107-0055	Dish Washer	1
33	ZT107-0056	Bolt	1
34	UG700-00132	Nut - M6	1
35	UR390-00084	Bolt - M6x35	1

Model: ZERO 107E

Frame




N	ART	Name	QTY
1	UA516-00037	Bolt - M10x80	4
2	UG806-00061	Nut - M10	6
3	UG700-00100	Washer - M10	26
4	UG806-00032	Bolt - M10x25	2
5	UR200-00067	Bolt - M10x20	2
6	UR200-00070	Spring Washer - 10x2.6	18
7	ZT107-0057	Seal plate	1
8	ZT107-0058	Pin	2
9	ZT107-0059	Connecting Rod	2
10	ZT107-0060	Pin	2
11	UR760-00138	Nut	3
12	ZT107-0061	Pin	2
13	U537-00060	Bolt - M8x20	6
14	U455-00061	Washer - 8x1.6	28
15	UZT85-00078	Nylon Bush	7
16	U455-00007	Lock Nut - M8	14
17	ZT107-0062	Shaft	1
18	ZT107-0063	connecting rod	1
19	UZT85-00076	Nylon Bush	7
20	ZT107-0064	Steady	7
21	UG390-00011	Bolt - M10x35	14
22	U537-00111	Lock Bolt - M10	2
23	ZT107-0065	Frame	1
24	ZT107-0066	Bolt - M8x45	4
25	ZT107-0067	Damper	2
26	ZT107-0068	Casing	2
27	ZT107-0069	Spring	2
28	UR760-00137	Shaft	1
29	ZT107-0070	Handle	1
30	ZT107-0071	Brake cable	1
31	UG700-00022	Bolt - M8	8
32	U455-00054	Washer - 6x1.6	8
33	UG700-00056	Spring Washer - 6x1.6	8
34	UG700-00055	Bolt - M6x20	8
35	ZT107-0072	Nut - M10	4
36	ZT107-0073	Washer	4
37	ZT107-0074	Brake switch	2
38	ZT107-0075	Handle	1
39	ZT107-0076	Pin - 2.8x50	7
40	ZT107-0077	Foot brake pedal	1
41	ZT107-0078	Brake cable	1
42	UV160-00035	Screw - M3x16	4
43	UV160-00036	Washer - 3x0.5	4
44	ZT107-0079	speaker	1
45	ZT107-0080	Index plate	1
46	UV160-00037	Lock Nut - M3	2
47	ZT107-0081	Pin	4
48	ZT107-0082	E-Clip - M15	4
49	ZT107-0083	Pull hook	2

50	ZT107-0084	connecting rod	1
51	UG806-00029	Bolt - M8x25	4
52	ZT107-0085	spring	1
53	ZT107-0086	Washer - 12x2.5	1
54	UR420-00008	Spring Washer - 8x2.4	8
55	ZT107-0087	Spring	1
56	ZT107-0088	Hanging rod	2
57	UT160-00062	Dust cover	2
58	ZT107-0089	Pedal	1
59	ZT107-0090	Pedal	1
60	ZT107-0091	Power	1
61	UT160-00046	Bolt - M8x60	4
62	ZT107-0092	Support beam	1
63	ZT107-0093	Pin - 3.2x20	1
64	ZT107-0094	Washer - 10x2.5	4
65	ZT107-0095	Mounting seat	1

Model: ZERO 107E


Controller



N	ART	Name	QTY
1	UR760-00041	Lock Nut - M4	6
2	UZT85-00135	Washer - 4x0.5	12
3	UR760-00040	Insulation pad	18
4	ZT107-0096	Pad	1
5	ZT107-0097	Mounting plate	1
6	ZT107-0098	Controller	4
7	ZT107-0099	Screw - M5x12	8
8	UR760-00039	Septum	6
9	ZT107-0100	Screw - M4x40	6

Model: ZERO 107E


Right handle part



N	ART	Name	QTY
1	ZT107-0101	Right handle	1
2	UG806-00029	Bolt - M8x25	2
3	UR420-00008	Spring Washer - 8x2.4	5
4	U455-00061	Washer - 8x1.6	5
5	UG806-00029	Bolt - M8x25	2
6	UR200-00079	Nut - M3	2
7	ZT107-0102	Pressure plate	1
8	ZT107-0039	Damping pad	2
9	UV160-00024	Screw - M3x20	2
10	UR200-00080	Spring Washer - 3x0.6	2
11	UV160-00036	Washer - 3x0.5	4
12	ZT107-0104	Pressure plate	1
13	ZT107-0041	Switch	1
14	ZT107-0106	Mounting plate	1
15	UG390-00064	Bolt - M8x55	1
16	UG700-00022	Nut - M8	2
17	UG390-00064	Bolt - M8x55	1
18	ZT107-0107	Shaft	1
19	ZT107-0044	Electronic throttle	1
20	ZT107-0109	Mounting plate	1
21	UZT85-00135	Washer - 4x0.5	2
22	ZT107-0046	Spring Washer - 4x1.1	2
23	ZT107-0047	Bolt - M5x35	2
24	ZT107-0112	Handle return	1
25	UG700-00056	Spring Washer - 6x1.3	2
26	UG700-00138	Bolt - M6x16	2
27	ZT107-0050	Lock Nut - M8	1
28	ZT107-0051	Hinge	1
29	ZT107-0052	Damping pad	1
30	ZT107-0116	Gasket	2
31	ZT107-0117	Connector	1
32	ZT107-0118	Dish Washer	1
33	ZT107-0119	Bolt	1
34	UG700-00132	Nut - M6	1
35	UR390-00084	Bolt - M6x35	1

Model: ZERO 107E


Rear Wheel



N	ART	Name	QTY
1	UR760-00139	Nut - M12	6
2	ZT107-0120	Rear wheel	2
3	U537-00023	Bolt - M8x35	4
4	UR420-00008	Spring Washer - 8x2.4	4
5	U455-00061	Washer - 8x1.6	4
6	ZT107-0121	pad	2
7	ZT107-0122	Rear Transmission Assembly	1
8	ZT107-0123	Motor	2
9	UAE55-00089	Screw - M6*25	4
10	ZT107-0124	Screw - M6*80	2
11	ZT107-0125	Screw - M6*40	4

Model: ZERO 107E


Front wheel



N	ART	Name	QTY
1	US270-00023	Bolt - M12x180	2
2	UR200-00074	Washer - ϕ 12	8
3	ZT107-0126	Sheath of wheel	4
4	ZT107-0127	Cap	4
5	UZT85-00094	Oil seal	4
6	ZT107-0128	Bearing	4
7	UZT85-00022	zerk M8x1	2
8	ZT107-0129	Front wheel	2
9	ZT107-0130	Inner shaft sheath of front wheel	2
10	UR200-00076	Lock Nut - M12	2
11	ZT107-0131	Front wheel bracket	2
12	UZT85-00100	Seal ring	2
13	ZT107-0132	Bearing	1
14	UT160-00068	Bearing	1
15	UT160-00067	Washer	2
16	UT160-00050	Lock nut - M20	2
17	UT160-00062	Cap	2

Model: ZERO 107E

Blade disc



N	ART	Name	QTY
1	U455-00013	Lock Nut - M6	20
2	U455-00054	Washer - 6x1.6	20
3	U455-00006	Lock Nut - M5	6
4	U506-00049	Washer - 5x1.6	6
5	ZT107-0133	Engine cover	2
6	ZT107-0134	Engine	2
7	ZT107-0135	Blade Disc	1
8	ZT107-0136	Wheel shaft	2
9	UR200-00074	Washer - 12x2.5	4
10	ZT107-0137	Scroll wheel	2
11	UR200-00076	Lock Nut - M12	2
12	UR810-00115	Engine base	2
13	UG700-00138	Bolt - M6x16	12
14	UG806-00023	Bolt - M5x16	6
15	UR760-00100	Adapter	2
16	ZT107-0138	Blade	2
17	U455-00049	Dish Washer	2
18	UT160-00022	Lock Nut - M10	2
19	U455-00007	Lock Nut - M8	1
20	U455-00061	Washer - 8x1.6	2
21	ZT107-0139	Deflector	1
22	ZT107-0140	Bolt - M8x170	1
23	ZT107-0141	Washer	2