


Gi 40 P Lawnmower

Документы

Complete illustrated parts list

---



## изображение Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	LR000093R	Upper hood				
2	1	LR000094R	Engine				
3	1	LR000095R	Wiring				
4	1	LR000096R	Starter assy				
5	4	LR000098R	Tightening handle				
6	1	LR000100R	Support				
7	1	LR000101R	Support				
8	2	LR000102R	Rear wheel kit				
9	1	LR000103R	Rear axle				
10	2	LR000104R	Wheel cover				
11	1	LR000106R	Lever				
12	1	LR000108R	Rod				
13	2	LR000109R	Wheel cover				
14	2	LR000110R	Front wheel kit				
15	1	LR000111R	Front axle				
16	1	54030001A	Battery				
16	1	54030031	Battery				
17	1	54030007	Battery charger				
18	1	LR000049R	Hub				
19	1	LR000050R	Blade				
20	1	LR000051R	Washer				
21	1	LR000053R	Screw				
22	1	LR000046R	Deck				
23	1	LR000074R	Counterweight				
24	1	LR000047R	Main board				
26	1	LR000017R	Safety key				
27	1	LR000032R	Shutter				
28	1	LR000014R	Cover				
29	1	LR000002R	Lever				
30	1	LR000003R	Handlebar				
31	1	LR000013R	Handle tube				
32	1	LR000085R	Locking kit				
33	1	LR000081R	Grassbag				
34	1	LR000018R	Shoe				
35	2	LR000034R	Handle				
36	1	LR000030R	Shaft				
37	1	LR000031R	Spring				
38	1	LR000036R	Plate				
39	1	LR000024R	Grip-end kit (male)				
40	1	LR000039R	Pin				
41	1	LR000037R	Magnet				
42	1	LR000035R	Deck cover				
43	2	LR000008R	Screw				
44	2	LR000007R	Band				
45	4	LR000009R	Gasket				
46	4	LR000010R	Nut				

## изображение Complete illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
47	4	LR000011R	Handle (locking)				
48	2	LR000007R	Band				
49	1	LR000004R	Support				
50	1	LR000005R	Spring				
51	1	LR000006R	Bracket support				
52	2	LR000073R	Wheel cover				
53	2	LR000075R	Wheel cover				
54	4	LR000055R	Nut				
55	2	LR000077R	Rear wheel				
56	1	LR000078R	Rear bracket				
57	4	LR000059R	Main board				
58	1	LR000079R	Rear axle				
59	1	LR000080R	Rear bracket				
60	1	LR000082R	Pin				
62	4	LR000055R	Nut				
65	1	LR000076R	Rear rod				
66	1	LR000062R	Front rod				
67	1	LR000070R	Gasket				
68	1	LR000069R	Ring				
69	2	LR000064R	Screw				
70	1	LR000062R	Front rod				
71	1	LR000071R	Spring				
72	1	LR000068R	Fulcrum				
73	2	LR000072R	Plate				
74	1	LR000067R	Bracket				
75	1	LR000065R	Handle				
76	2	LR000052R	Wheel cover				
77	2	LR000054R	Wheel cover				
78	2	LR000056R	Front wheel				
79	1	LR000060R	Front bracket				
80	3	LR000061R	Pin				
81	4	LR000059R	Main board				
82	1	LR000058R	Front axle				
83	1	LR000057R	Front bracket				
84	1	LR000085R	Locking kit				