

OM 102R/19 K V Cat: 2025 Garden tractor



Документы

Mulching Kit

Grassbag

Mowing deck

Engine

Tank

Transmission

Frame

Front axle

Steering arm

Rear axle


Seat

Cutting plate lifting

Electrical parts


Body

Towing hitch




изображение Mulching Kit

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000047R	Knob				
2	2	TS000048R	Spring				
3	1	TS000049R	Handle				
4	1	TS000050R	Spring				
5	1	TS000051R	Pin				
6	1	TS000003R	Deflector				




изображение Grassbag

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000052R	Exhaust				
5	1	TS000053R	Exhaust pipe				
6	2	TS000054R	Screw				
7	1	TS000055R	Cap				
9	1	TS000056R	Knob				
10	1	TS000057R	Lever				
11	1	TS000058R	Gasket				
12	1	TS000004R	Grass-bag cover				
13	1	TS000413R	Frame				
14	1	TS000060R	Cover				
17	1	TS000061R	Frame				
18	2	TS000062R	Bracket				
19	1	TS000380R	Grass collector			Oleo-Mac	




изображение Mowing deck

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000108R	Belt cover				
4	1	TS000064R	Bracket				
5	1	TS000065R	Screw				
7	4	TS000066R	Clamp				
9	1	TS000067R	Spring				
11	1	TS000068R	Nipple				
12	1	TS000069R	Lever				
14	1	TS000070R	Bushing				
15	2	TS000071R	Screw				
16	1	TS000072R	Pulley				
17	1	TS000073R	Bearing				
18	2	TS000074R	Wheel				
21	1	TS000109R	Mowing deck				
22	1	TS000076R	Bushing				
24	2	TS000005R	Bearing				
25	2	TS000006R	Pulley				
26	1	TS000077R	Screw				
27	1	TS000110R	Belt				
28	1	TS000079R	Bracket				
29	2	TS000090R	Water hose connection				
31	2	TS000089R	Rivet				
32	1	TS000080R	Blade shaft				
33	4	TS000086R	Bearing				
34	2	TS000085R	Disc (guard)				
35	2	TS000111R	Pulley				
36	2	TS000082R	Key				
40	1	TS000081R	Screw				
41	1	TS000087R	Blade shaft				
44	1	TS000112R	Belt cover				
45	2	TS000091R	Plate				
46	2	TS000092R	Tube				
47	2	TS000093R	Support				
48	2	TS000094R	Spacer				
50	2	TS000095R	Blade hub				
51	1	TS000113R	Blade left				
52	2	TS000097R	Washer				
54	1	TS000098R	Screw				
55	2	TS000099R	Key				
56	1	TS000114R	Blade right				
57	1	TS000408R	Screw				




изображение Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000147R	Knob				
4	1	TS000430R	Throttle cable				
7	1	TS000009R	Key				
8	1	TS000159R	Pulley			Motore 14,5 K / 16 K / 19	
10	1	TS000010R	Support				
12	1	TS000149R	Clutch				
13	1	TS000150R	Bushing				
14	1	TS000151R	Thickness				
15	1	TS000152R	Bolt				
16	1	TS000153R	Plate				
18	1	TS000436R	Bracket			Motore 14,5 K / 16 K /19	
23	1	TS000431R	Muffler			KV- Engine 14,5 K / 16 K	
24	2	TS000156R	Gasket			/19 KV	
25	1	TS000432R	Grid				
29	1	TS000158R	Support				




изображение Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
10	1	TS000012R	Filter				
11	1	TS000161R	Tank				
13	2	TS000162R	Band				
14	1	TS000163R	Fuel hose				
16	1	TS000013R	Tank cap				




изображение Transmission

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	2	TS000173R	Bushing				
3	1	TS000253R	Spacer				
5	1	TS000255R	Support				
6	1	TS000130R	Spring				
8	1	TS000122R	Bushing				
9	1	TS000007R	Pulley				
11	1	TS000006R	Pulley				
12	1	TS000005R	Bearing				
16	1	TS000263R	Plate				
20	1	TS000259R	Screw				
21	1	TS000025R	Belt				
23	3	TS000023R	Pulley				
24	2	TS000260R	Bushing				
27	1	TS000264R	Guide pulley				



изображение Frame

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000165R	Right footboard support				
4	1	TS000166R	Footrest pad				
5	1	TS000167R	Right footboard cover				
8	1	TS000168R	Right footboard support				
10	2	TS000169R	Bushing				
12	1	TS000170R	Frame				
13	1	TS000171R	Hood support RX				
14	1	TS000172R	Support				
15	4	TS000014R	Washer				
16	1	TS000015R	Bumper				
17	4	TS000173R	Bushing				
18	1	TS000016R	Bumper				
19	1	TS000017R	Lower hood				
22	1	TS000174R	Support				
23	1	TS000175R	Support				
25	2	TS000176R	Plate				
26	1	TS000177R	Column support				
28	1	TS000178R	Left footboard support				
29	1	TS000179R	Footrest pad				
30	1	TS000180R	Left footboard cover				
31	1	TS000181R	Frame				
32	2	TS000182R	Seat support				
33	1	TS000183R	Left footboard support				
34	1	TS000184R	Support				
35	2	TS000185R	Support				
36	1	TS000186R	Support				
37	1	TS000187R	Support				
41	1	TS000416R	Support				
42	1	TS000189R	Bracket				
43	1	TS000190R	Hook				
44	1	TS000191R	Hook				
45	2	TS000192R	Screw				
47	2	TS000193R	Spring				
48	1	TS000194R	Left bracket				
49	1	TS000195R	Right bracket				
51	1	TS000196R	Support				
52	1	TS000197R	Bracket				




изображение Front axle

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	TS000198R	Hub cap				
3	2	TS000199R	Washer				
4	4	TS000200R	Spacer				
5	2	TS000018R	Complete wheel				
5.4	4	TS000204R	Bearing				
6	1	TS000019R	Pin				
8	4	TS000020R	Bushing				
9	1	TS000205R	Front axle				
11	1	TS000021R	Lever				
17	1	TS000206R	Spacer				
18	2	TS000068R	Nipple				
21	1	TS000022R	Pin				


изображение Steering arm

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000267R	Angle joint				
3	1	TS000268R	Tie rod				
5	1	TS000269R	Plate				
8	1	TS000270R	Sleeve				
9	1	TS000271R	Bushing				
10	1	TS000272R	Snap ring				
11	1	TS000273R	Steering arm				
13	2	TS000274R	Bushing				
14	1	TS000275R	Tie rod				
16	1	TS000026R	Sprocket				
17	1	TS000276R	Pin				
19	1	TS000378R	Bushing				
20	1	TS000277R	Bushing				
21	1	TS000278R	Cotter pin				
22	1	TS000279R	Fixing plate				
23	2	TS000280R	Bushing				
24	1	TS000027R	Sector				
25	1	TS000281R	Fixing plate				
26	1	TS000282R	Angle joint				
28	1	TS000283R	Spacer				
30	1	TS000284R	Steering wheel				
31	1	TS000028R	Support				
32	1	TS000379R	Washer				
33	1	TS000376R	Cover			Arancio - Orange	




изображение Rear axle

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	TS000198R	Hub cap				
2	2	TS000207R	Snap ring				
3	4	TS000199R	Washer				
4	2	TS000212R	Complete wheel				
5	2	TS000210R	Key				
8	1	TS000240R	Plate				
10	1	TS000241R	Transmission				
11	1	TS000242R	Pin				
15	1	TS000243R	Support				
17	1	TS000244R	Brake cable				
18	1	TS000245R	Clamp cover rear				
19	1	TS000246R	Pedal				
23	1	TS000247R	Pin				
25	1	TS000248R	Tie rod				
27	1	TS000249R	Plate				
29	1	TS000250R	Spring				
30	2	TS000231R	Support				
32	1	TS000230R	Support				
33	1	TS000251R	Clamp cover front				
37	1	TS000232R	Bushing				
38	1	TS000233R	Control				
40	1	TS000234R	Control rod				
41	1	TS000235R	Handle				
42	1	TS000236R	Fork				
43	1	TS000237R	Spring				
44	1	TS000439R	Brake pedal				
45	1	TS000239R	Cover moulding				




изображение Seat

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000285R	Support				
4	2	TS000286R	Spring				
7	2	TS000287R	Cover				
8	1	TS000418R	Seat support				
9	2	TS000289R	Screw				
10	2	TS000290R	Slide				
12	1	TS000029R	Seat switch				
13	1	TS000373R	Seat			Arancio - orange	
14	4	TS000291R	Spacer				




изображение Cutting plate lifting

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
3	2	TS000292R	Rod				
4	1	TS000293R	Tie rod				
6	1	TS000294R	Angle joint				
10	1	TS000295R	Rod				
11	1	TS000296R	Axel lift				
12	1	TS000297R	Rod				
13	1	TS000298R	Support				
15	4	TS000231R	Support				
16	2	TS000299R	Angle joint				
17	1	TS000300R	Rod				
19	1	TS000301R	Plate				
20	1	TS000226R	Knob				
21	1	TS000030R	Support				
22	1	TS000302R	Spring				
25	1	TS000303R	Spring				
26	1	TS000031R	Lever				
27	1	TS000223R	Snap ring				
28	2	TS000378R	Bushing				
29	1	TS000304R	Lever group				
30	1	TS000305R	Tie rod				
31	1	TS000306R	Tie rod				
32	1	TS000307R	Angle joint				




изображение Electrical parts

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000314R	Cable				
2	1	TS000440R	Wiring				
3	20	TS000316R	Band				
3	2	TS000317R	Band				
4	1	TS000319R	Cable				
5	1	TS000032R	Switch				
6	1	TS000320R	Indicator				
7	1	TS000321R	Snap ring				
9	1	TS000033R	Solenoid				
12	1	TS000323R	Clamp				
14	1	TS000324R	Wire				
15	1	TS000325R	Fuse				
16	1	TS000034R	Switch				
17	1	TS000326R	Switch				
18	1	TS000035R	Shoe				
19	1	TS000327R	Bracket				
20	2	TS000036R	Micro-switch				
25	1	TS000328R	Fixing plate				
28	1	TS000329R	Lever				
29	1	TS000330R	Lever				
33	1	TS000331R	Switch				
34	1	TS000332R	Belt				
35	1	TS000038R	Battery				
36	2	TS000333R	Bracket				
38	1	TS000336R	Control lever				
39	1	TS000037R	Micro-switch				
40	1	TS000337R	Bracket				
41	1	TS000435R	Switch				
43	1	68050054	Support + switch kit				
44	1	TS000318R	Switch protection				
45	1	68130481	Battery charger				
46	1	TS000412R	Starting key				



изображение Body

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	TS000340R	Wiring				
2	1	TS000341R	Adapter				
3	1	TS000342R	Deflector				
4	1	TS000343R	Right guard				
6	5	TS000344R	Fairled				
7	1	TS000361R	Right guard			Arancione - orange	
10	2	TS000345R	Pin				
11	1	TS000441R	Headlamp				
12	1	TS000364R	Guard			Arancione - orange	
13	1	TS000039R	Upper hood				
14	1	TS000442R	Headlamp				
15	1	TS000367R	Engine cover			Arancione - orange	
16	1	TS000370R	Left guard			Arancione - orange	
17	1	TS000348R	Left guard				
19	1	TS000349R	Cover				
20	4	TS000350R	AV-mount				
22	1	TS000351R	Dashboard				
23	15	TS000066R	Clamp				
24	1	TS000352R	Panel				
25	1	TS000040R	Cover				
27	1	TS000353R	Housing				
28	1	TS000041R	Wheels cover				
30	1	TS000354R	Housing				
31	1	TS000355R	Panel				
34	1	TS000357R	Lock				



изображение Towing hitch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	1	TS000358R	Towing hitch				
3	2	TS000359R	Spacer				