



GIRO 700C


A




B




C




D




E




F




I




H



G



J



GIRO Spare parts list

subassembly code	Name_English	parts list
1	handle	handle
2	deck	deck
3	regulator	regulator
4	tensional pulley	tensional pulley
5	gear box	gear box
6	rear axle	rear axle
7	reducer	reducer
8	brush	brush
9	dozer	dozer
10	collector	collector
2018	Sweeper	

1 handle Spare parts list			
Order	Part number	Name_English	Quantity
1	UG700-00001	sheath	2
2	UG700-00002	right grip	1
3	UG700-00003	handle	1
4	U455-00013	lock nut	4
5	UG700-00004	screw	1
6	UG700-00005	check ring	2
7	UG700-00006	left grip	1
8	UG700-00007	screw	2
9	UG700-00008	screw	1
10	UG700-00009	clutch cable	1
11	UG700-00010	tensional cable	1
12	UG700-00011	bolt	4
13	UG700-00012	plate	2
14	UG700-00013	bracket	4
15	UG700-00014	square neck bolt	1
16	U506-00035	screw	1
17	U506-00036	knob	1
18	UG700-00015	throttle bracket	1
19	UG700-00016	clutch cable bracket	2
20	UG700-00017	throttle cable	1
21	UG700-00018	cable clip	1
22	UG700-00019	knob	1
23	U455-00054	spacer	6
24	U455-00053	spring washer	1
25	U455-00061	spacer	1

2	Deck Spare parts list		
Order	Part number	Name_English	Quantity
1		engine	1
2	UG700-00020	handle sheath	1
3	UG700-00021	steering rod	1
4	UG700-00022	nut	6
5	U506-00011	key	1
6	UG700-00023	spacer	1
7	U455-00053	spring washer	9
8	U455-00061	spacer	9
9	UG700-00024	pulley	1
10	U455-00049	spring washer	1
11	UG700-00025	central bolt	1
12	U537-00022	spacer	4
13	UG700-00026	bolt	4
14	U455-00002	bolt	1
15	U455-00025	rubber ring	1
16	UG700-00027	cover	1
17	U537-00094	hex flange bolt	4
18	UG700-00028	stopper	2
19	UG700-00029	bolt	2
20	UG700-00030	bracket	1
21	UG700-00031		
22	U506-00058	big washer	2
23	U537-00060	bolt	2
24	UG700-00032	check ring	1
25	UG700-00033	spring pin	1
26	UG700-00034	pulley	1
27	UG700-00035	belt	1
28	UG700-00036	spring	1
29	UG700-00037	screw	5
30	UG700-00038	big washer	5
31	UG700-00039	front cover	1
32	UG700-00040		
33	UG700-00041	bolt	2

3			
Regulator Spare parts list			
Order	Part number	Name_English	Quantity
1	UG700-00042	pin	1
2	UG700-00043	knob	1
3	UG700-00044	check ring	1
4	UG700-00045	nylon bush	1
5	UG700-00046	rod weldment	1
6	UG700-00047	tube	1
7	U537-00060	bolt	8
8	U455-00061	spring	12
9	U455-00007	lock nut	8
10	UG700-00048	check ring	1
11	UG700-00049	big spacer	1
12	UG700-00050	spring	1
13	UG700-00051	shaft	1
14	UG700-00052	wheel	1

4	Tensional Pulley Spare parts list		
Order	Part number	Name_English	Quantity
1	U455-00077	check ring	1
2	UR200-00074	spacer	1
3	UG700-00053	nylon bush	1
4	UG700-00054	pulley weldment	1
5	UG700-00055	bolt	1
6	UG700-00056	spring washer	1
7	U455-00044	big washer	1
8	UG700-00057	check ring	1
9	UG700-00058	bearing	1
10	UG700-00059	pulley	1
11	U537-00060	bolt	1
12	U455-00053	spring washer	1
13	U506-00058	big washer	1
14	UG700-00060	check ring	1
15	UG700-00061	bearing	1
16	UG700-00062	pulley	1
17	UG700-00063	tensional arm	1

5	Gear Box Spare parts list		
Order	Part number	Name_English	Quantity
	UG700-00064	gear box	1
1	UG700-00065	pin	2
2	UG700-00066	shaft	1
3	UG700-00067	bearing	1
4	UG700-00068	oil seal ring	2
5	UG700-00069	bearing	2
6	UG700-00070	spacer	1
7	UG700-00071	spacer	1
8	UG700-00072	spacer	4
9	UG700-00069	bearing	2
10	UG700-00074	worm wheel	1
11	UG700-00075	taper bush	2
12	UG700-00076	pulley	1
13	UG700-00077	spring pin	1
14	UG700-00078	spring	1
15	U455-00006	lock nut	1
16	UG700-00038	big washer	1
17	UG700-00080	arm	1
18	UG700-00081	upper case	1
19	UG700-00082	oil seal ring	1
20	UG700-00083	bearing	2
21	UG700-00084	worm	1
22	UG700-00085	o ring	1
23	UG700-00086	bottom case	1
24	UG700-00087	lock screw	9
25	UG700-00088	cam	1
26	UG700-00089	cam	1
27	UG700-00090	shaft	1
28	UG700-00091	bearing	1
29	UG700-00092	pin	1
30	UG700-00093	sprocket wheel	1
31	UG700-00094	check ring	1

6 Rear Axle Spare parts list			
Order	Part number	Name_English	Quantity
1	UG700-00095	bolt	2
2	U455-00053	spring washer	2
3	U506-00058	big washer	2
4	UG700-00096	bearing	4
5	UG700-00097	wheel	2
6	UG700-00098	clutch bush	2
7	U455-00068	check ring for shaft	2
8	U537-00111	lock nut	4
9	U455-00029	spacer	6
10	UG700-00099	bearing	2
11	UG700-00100	big washer	2
12	UG700-00101	bolt	4
13	UG700-00102	pin	2
14	UG700-00103	rear axis assembly	1
15	UG700-00104	chain	1
16	UG700-00105	bolt	4
17	UG700-00056	spring washer	4
18	U455-00054	spacer	4
19	UR200-00073	nut	1
20	UG700-00107	bolt	1
21	UG700-00108	belt	1
22	UR200-00074	spacer	2

7 Reducer spare parts list			
Order	Part number	Name_English	Quantity
	UG700-00109	reducer	1
1	UG700-00110	oil seal ring	1
2	UG700-00111	check ring	2
3	UG700-00112	bearing	2
4	UG700-00113	worm	1
5	UG700-00114	case	1
6	UG700-00115	bolt	8
7	UG700-00116	bolt	3
8	UG700-00056	spring washer	8
9	UG700-00118	cover	2
10	UG700-00119	oil seal ring	2
11	UG700-00120	bearing	2
12	UG700-00121	worm wheel	1
13	U455-00068	check ring for shaft	1
14	UG700-00122	cover	1
15	UG700-00123	bearing	1

8	Brush spare parts list		
Order	Part number	Name_English	Quantity
1	UG700-00124	rod	1
2	UG700-00125	disc	2
3	UG700-00126	brush	2
4	UG700-00127	adapter	2
5	UG700-00128	bush	2
6	UG700-00129	bolt	10
7	UG700-00130	rubber	2
8	UG700-00131	plate	2
9	U455-00054	spacer	10
10	UG700-00132	lock nut	10
11	UG700-00133	spacer	1
12	UG700-00134	bearing	1
13	UG700-00135	spring	1
14	UG700-00136	lock pin	2
15	UG700-00137	bracket weldment	1
16	UG700-00138	bolt	6
17	UG700-00056	washer	6
18	U537-00023	bolt	2
19	U455-00061	spacer	6
20	U455-00007	lock nut	4
21	UG700-00140	spring	2
22	UG700-00141	plate	1
23	U455-00029	spacer	1
24	U537-00111	lock nut	1

9		Dozer Spare parts list	
Order	Part number	Name_English	Quantity
		blade assembly	1
1	UG700-00142	bolt	1
2	UG700-00143	rubber block	1
3	U455-00029	spacer	1
4	U537-00111	lock nut	2
5	UG700-00144	blade	1
6	U455-00007	lock nut	5
7	U455-00061	spacer	5
8	UG700-00145	guide	2
9	UG700-00146	rubber plate	1
10	UG700-00147	plate	1
11	UG700-00014	square neck bolt	5

10		Collector Spare parts list	
Order	Part number	Name_English	Quantity
	UG700-00149	collector assembly	1
1	UG700-00150	rubber	1
2	UG700-00129	bolt	12
3	U455-00044	big washer	15
4	U455-00013	nut	20
5	U455-00054	spacer	9
6	UG700-00138	bolt	4
7	UG700-00153		2
8	UG700-00154	rubber	1
9	UG700-00155	collection box	1
10	UG700-00156	collector weldment	1
11	U455-00032	spring	2
12	UR200-00074	spacer	6
13	UG700-00157	bush	4
14	UG700-00158	bracket	2
15	U455-00007	nut	2
16	U455-00061	spacer	4
17	UG700-00159	bolt	2
18	UG700-00160	bush	4
19	UG700-00161	wheel	2