

**Listino ricambi VIBRATORI FLEX serie FX -2014****Spare parts price list for FLEXIBLE VIBRATOR - FX - 2014**

Pos.	Cod.	Descrizione	description
16	FX0100	Giunto esagonale femmina	Female exagonal coupling
12	FX0200	Manicotto di traino FX x tutti i Ø	sleeve driver Fx (for all Ø)
10	FX0300	Corda flessibile / mt.	flexible shaft /mt
9	FX0400	Giunto traino eccentrico x Ø 30-34-38-43-50-60	coupling-eccentric-drive Ø 30-34-38-43-50-60
9	FX0425	Giunto traino eccentrico x Ø 25	coupling-eccentric-drive Ø 25
14	FX0500	Manicotto innesto	coupling sleeve
15	FX0600	Ghiera manicotto	sleeve ring nut
11	FX0700	Tubo flessibile / m.	flexible hose
8	FX0825	Supporto posteriore diam. 25	rear support Ø 25
8	FX0830	Supporto posteriore diam. 30	rear support Ø 30
8	FX0834	Supporto posteriore diam. 34	rear support Ø 34
8	FX0838	Supporto posteriore diam. 38	rear support Ø 38
8	FX0843	Supporto posteriore diam. 43	rear support Ø 43
8	FX0850	Supporto posteriore diam. 50	rear support Ø 50
8	FX0860	Supporto posteriore diam. 60	rear support Ø 60
3	FX0925	Cuscinetto diam. 25 - 607zz	bearing diam. 25
3	FX0930	Cuscinetto diam. 30 - 608zz	bearing diam. 30
3	FX0934	Cuscinetto diam. 34 - 6001zz	bearing diam. 34
3	FX0938	Cuscinetto diam. 38 - 6201zz	bearing diam. 38
3	FX0943	Cuscinetto diam. 43 - 6202zz	bearing diam. 43
3	FX0950	Cuscinetto diam. 50 - 6302zz	bearing diam. 50
3	FX0960	Cuscinetto diam. 60 - 6304zz	bearing diam. 60
5	FX1125	Eccentrico tondo diam. 25	eccentric diam. 25
5	FX1130	Eccentrico tondo diam. 30	eccentric diam. 30
5	FX1134	Eccentrico tondo diam. 34	eccentric diam. 34
5	FX1138	Eccentrico tondo diam. 38	eccentric diam. 38
5	FX1143	Eccentrico tondo diam. 43	eccentric diam. 43
5	FX1150	Eccentrico tondo diam. 50	eccentric diam. 50
5	FX1160	Eccentrico tondo diam. 60	eccentric diam. 60
4	FX1225	Canna diam. 25	steel tube diam. 25
4	FX1230	Canna diam. 30	steel tube diam. 30
4	FX1234	Canna diam. 34	steel tube diam. 34
4	FX1238	Canna diam. 38	steel tube diam. 38
4	FX1243	Canna diam. 43	steel tube diam. 43
4	FX1250	Canna diam. 50	steel tube diam. 50
4	FX1260	Canna diam. 60	steel tube diam. 60
1	FX1325	Testina + o.r diam.25	head + o.r. diam.25
1	FX1330	Testina + o.r diam.30	head + o.r. diam.30
1	FX1334	Testina + o.r diam.34	head + o.r. diam.34
1	FX1338	Testina + o.r diam.38	head + o.r. diam.38
1	FX1343	Testina + o.r diam.43	head + o.r. diam.43
1	FX1350	Testina + o.r diam.50	head + o.r. diam.50
1	FX1360	Testina + o.r diam.60	head + o.r. diam.60



Listino ricambi **UNITA' MOTRICE serie FX -2014**

Spare parts price list for **DRIVE UNIT - FX-2014**

Pos.	Cod.	Descrizione	description
1/2	FX0001	Carcassa fronte / retro	housing
4	FX0002	Dado cieco M5	blind nut
5	FX0003	Porta cuscinetti (muso)	bearing holder
6	FX0004	Ventola	fan
7	FX0005	Tappo	plug
8	FX0006	Tappo vite spazzola	cap-brush-screw
9	FX0007	Spazzola	brush
10	FX0008	Rotore	rotos assembly
11	FX0009	Cuscinetto d. 28x12x8 - 6001	bearing Ø 28x12x8
12	FX0010	Anello compensazione	compensation ring
13	FX0011	Statore	stator assembly
14	FX0012	Porta spazzole	brush holder
15	FX0013	Cuscinetto d.35x17x10-6003	bearing Ø 35x17x10
16	FX0014	Fissacavo in ferro 10/12	iron cable clamp
17	FX0015	Passacavo	cable entry fitting
18	FX0016	Protezione interruttore	plastic cover switch
18	FX0017	Interruttore	switch
19	FX0018	Vite M5x90	screw M5x90
20	FX0019	Vite M5x20	screw M5x20
22	FX0020	Cavo 3G1,5 – prezzo al pezzo 1,5mt	cable 3G1,5
22	FX0021	Spina 220V	plug 220V
25	FX0024	Boccola completa	complete bushing
26	FX0025	Anello cuscinetto	ring bearing
28	FX0028	cuscinetto 35x15x11 (6202zz)	bearing 35x15x11
29	FX0029	seeger/anello di tenuta	seeger
30	FX0030	conghia con ganci	belt



# LISTINO RICAMBI VIBRATORI FLEX SERIE FX

