


GRIDO 390H Machine Parts Breakdown



CODE	ART	NAME	QTY
1	UG390-00001	chassis	1
2	UG390-00002	cutting means assembly	1
2.11	UG390-00003	cutting disc	1
2.2	UG390-00004	inner hex bolt	8
2.12	UG390-00005	blade bracket2	4
2.13	UG390-00006	blade bracket1	4
2.5	UT160-00022	hex lock nut	3
2.14	UG390-00007	blade3	2
2.15	UG390-00009	blade1	4
2.16	UG390-00008	blade2	2
2.9	UG390-00010	spindle	1
2.10	UG390-00011	hex bolt	3
3	UG390-00012	spherical surface bearing sets	2
4	UG390-00013	hex bolt	4
5	UR200-00074	washer	4
6	UR200-00076	hex lock nut	4
7	UG390-00014	brake drum	1
8	UT160-00068	bearing	4
9	UG390-00015	brake belt	1
10	UT160-00069	seal ring	2
11	UT160-00064	wheel	2
12	UG390-00016	washer	2
13	UT160-00066	hex nut	2
14	UG390-00017	cotter pin	2
15	UT160-00063	nut of wheel hub	6
16	UT160-00062	hub cap	2
17	UG390-00018	bearing sheath	1
18	UG390-00019	belt cover	1
19	UG390-00020	washer	1
20	U455-00053	spring washer	2
21	UG806-00029	hex bolt	4
22	UG390-00021	engine	1
23	UG390-00022	spacer	1
24	UG390-00023	key	1
25	UG390-00024	engine pulley	1
26	UG390-00025	pulley of cutting means	1
27	UG390-00026	washer	1
28	UG390-00027	guiding wheel	2
28.1	UG390-00028	shaft	2
28.2	UG390-00029	wheel	2
28.3	UG390-00030	bearing	4
28.4	UG390-00031	check ring	2
29	UG390-00032	belt cover	1
30	UG390-00033	hex bolt	3
31	U455-00007	hex lock nut	19
32	UG390-00034	square neck bolt	4
33	U455-00029	washer	7
34	UR200-00070	spring washer	5
35	UG806-00061	nut	4
36	UG390-00035	hex bolt	2
37	UG390-00036	rear deflector	1
38	UG390-00037	front deflector	1
39	UG700-00095	hex bolt	7
40	UG390-00038	handle pivot	1
41	UG390-00039	spacer	2
42	UG390-00040	inner hex lock screw	2
43	UG390-00041	brake sliding pin	2
44	UG390-00042	brake spring	1

45	UG390-00043	brake cable clamp	1
46	UG700-00055	hex bolt	1
47	UG390-00044	handle assembly	1
47.1	UG390-00045	handle	1
47.2	UG390-00046	wheel brake handle assembly	1
47.2.1	UG390-00047	adjusting lever	1
47.2.2	UG390-00048	screw rod	1
47.2.3	UG390-00049	linkage	1
47.2.4	UG390-00050	bracket1	1
47.2.5	UG390-00051	bracket2	1
47.2.6	UG390-00052	cable connector	1
47.2.7	UG806-00038	spring pin	1
47.2.8	UG390-00053	pin	1
47.2.9	UG390-00054	spacer	1
47.2.10	UG700-00026	hex bolt	4
47.2.11	UG390-00055	lever	1
47.2.12	UG390-00056	grip	1
47.2.13	UG390-00057	spacer	1
47.2.14	UG390-00058	brake lever	1
47.2.15	UG390-00059	check ring	1
47.2.16	UG390-00060	cable sheath	1
47.2.17	UG390-00061	cable	1
47.2.18	UG390-00062	cable sheath connector	1
47.3	UG390-00063	control lever	1
47.4	UG390-00064	hex bolt	2
47.5	UG390-00065	spring	1
47.6	UG390-00066	switch	1
47.7	UG390-00067	adjusting screw	1
47.8	UG390-00068	switch linkage	1
47.9	UG390-00069	pin	1
47.10	UG390-00070	spring	1
47.11	UR200-00071	washer	1
47.12	UG390-00071	cotter pin	1
47.13	UG390-00072	grip	1
47.14	UG390-00073	switch	1
47.15	UG700-00022	nut	1
48	UG390-00074	belt	1
49	U455-00061	washer	25
50	UG390-00075	elbow	1
51	U506-00035	cross slot ST screw	2
52	UG390-00076	key	1
53	UT160-00083	hex bolt	1
54	UG390-00077	clamp	1
55	UG390-00078	washer	4
56	UG390-00079	hex bolt	2