0 24847 39325 5

FORM MS3513 REV M 02/25/2013
REPLACES FORM MS3513 REV L 01/29/2013
FILE IN SECT. 2 OF SERVICE MANUAL

Illustrated Parts List

Model Series

100600

TYPE NUMBERS
0001 THROUGH 5025.

TABLE OF CONTENTS

Air Cleaner 4
Alternator 6
Blower Housing 5
Brake 6
Cam Gear 2
Carburetor 3
Carburetor Overhaul Kit 3
Controls 6
Crankcase Cover/Sump 2
Crankshaft 2
Cylinder 2
Cylinder Head 2
Gasket Sets 7
Exhaust System 5
Flywheel 5
Fuel Supply 4
Governor Spring 6
Ignition 6
Lubrication 4
Piston, Rings, Connecting Rod 2
Rewind Starter 5

Not for Reproduction

PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

100600























1319 WARNING LABEL

REQUIRED *when replacing parts with warning labels affixed.*

1319A WARNING LABEL

REQUIRED *when replacing parts with warning labels affixed.*

1058 OPERATOR'S MANUAL

1330 REPAIR MANUAL

1036 EMISSIONS LABEL



Not for Reproduction

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine .







Not for Reproduction

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine .

100600



Not for Reproduction







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine .



























SAE METRIC











Not for Reproduction

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine .

100600



Not for Reproduction





Not for Reproduction

100600

REF. NO.	PART NO.	DESCRIPTION
1	**793508**	Cylinder Assembly
2	**796961**	Kit-Bushing/Seal
3	**299819s**	Seal-Oil (Magneto Side)
4	**793509**	Sump-Engine
5	**793502**	Head-Cylinder
7	**793455**	Gasket-Cylinder Head
9	**793439**	Gasket-Breather
11	**793447**	Tube-Breather
12	**793445**	Gasket-Crankcase (.015" Thick) (Standard)
13	**793451**	Screw (Cylinder Head)
15	**691680**	Plug-Oil Drain
16	**793615**	Crankshaft
		------- Note -----
		793429 Crankshaft Used on Type No(s). 0110, 0111, 0124, 0126, 0128, 0131, 0133, 0138, 0144, 0152, 0158, 0160, 0178, 0179, 2110, 2111, 2124, 2126, 2128, 2131, 2133, 2136, 2138, 2150, 3110, 3111, 3124, 3126, 3128, 3133, 3138, 3150, 3152, 3160.
		793426 Crankshaft Used on Type No(s). 0025, 0100, 0121, 0122, 0129, 0139, 0145, 0155, 0168, 0173, 0174, 0186, 0187, 0550, 0584, 0585, 0718, 0771, 0980, 0983, 1144, 1442, 2025, 2121, 2122, 2129, 2139, 2144, 2145, 2152, 2153, 2550, 2584, 2585, 2771, 2980, 2983, 3129, 3980, 5025.
		793616 Crankshaft Used on Type No(s). 0112, 0116, 0119, 0120, 0153, 0154, 0164, 0165, 2112, 2116, 2119, 2120, 3112, 3116, 3153, 3154, 3164, 3165.

REF. NO.	PART NO.	DESCRIPTION
20	**399781s**	Seal-Oil (PTO Side)
22	**793450**	Screw (Crankcase Cover/Sump)
23	**590420**	Flywheel
		------- Note -----
		793682 Flywheel Used on Type No(s). 0118, 0129, 0150, 0158, 0161, 2118, 2129, 2147, 2148, 3129, 3147, 3148, 3161.
24	**222698s**	Key-Flywheel
25	**793519**	Piston Assembly (Standard)
		------- Note -----
		793518 Piston Assembly (.020" Oversize)
26	**793435**	Ring Set (Standard)
		------- Note -----
		793517 Ring Set (.020" Oversize)
27	**691588**	Lock-Piston Pin
28	**298909**	Pin-Piston (Standard)
29	**793510**	Rod-Connecting
32	**691664**	Screw (Connecting Rod)
32A	**695759**	Screw (Connecting Rod)
33	**793505**	Valve-Exhaust
34	**793504**	Valve-Intake
35	**793506**	Spring-Valve (Intake)
36	**793506**	Spring-Valve (Exhaust)
37	**793473**	Guard-Flywheel
37A	**794106**	Guard-Flywheel Used on Type No(s). 0116, 0120, 0152, 0154, 0165, 0167, 0171, 0174, 0584, 0685, 0718, 2116, 2120, 2136, 2584, 3116, 3152, 3154, 3165, 3167, 3685.
40	**793503**	Retainer-Valve
51	**692555**	Gasket-Intake
58	**697316**	Rope-Starter (88 5/8" Long)

REF. NO.	PART NO.	DESCRIPTION
60	**281434s**	Grip-Starter Rope (Standard Grip)
60A	**799716**	Grip-Starter Rope (Ergonomic Grip)
75	**691736**	Washer (Flywheel)
78	**793480**	Screw (Flywheel Guard)
81	**691740**	Lock-Muffler Screw
104	**698536**	Pin-Float Hinge
104B	**592486**	Pin-Float Hinge
105	**698537**	Valve-Float Needle
105B	**592491**	Valve-Float Needle
117A	**793694**	Jet-Main (Standard)
		------ Note ------
		793466 Jet-Main (Standard) Used on Type No(s). 0100.
117B	**592490**	Jet-Main (Standard)
118A	**793695**	Jet-Main (High Altitude)
		------ Note ------
		793467 Jet-Main (High Altitude) Used on Type No(s). 0100.
118B	**592142**	Jet-Main (High Altitude)
121	**793622**	Kit-Carburetor Overhaul
121B	**592483**	Kit-Carburetor Overhaul
122	**793456**	Spacer-Carburetor
125A		Carburetor (For Replacement, Order Reference 125B)
125B	**591852**	Carburetor
133	**698539**	Float-Carburetor
133B	**592487**	Float-Carburetor
137	**698538**	Gasket-Float Bowl
137B	**592485**	Gasket-Float Bowl
163	**691894**	Gasket-Air Cleaner
187	**791766**	Line-Fuel (Cut to Required Length)

Not for Reproduction

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION
202	**793433**	Link-Mechanical Governor
		------- Note -----
		793444 Link-Mechanical Governor Used on Type No(s). 0100.
209	**793430**	Spring-Governor
		------- Note -----
		793427 Spring-Governor Used on Type No(s). 0001, 0002, 0015, 0025, 0100, 0151, 0168, 0550, 0584, 0585, 0718, 1144, 1442, 2015, 2025, 2144, 2550, 2584, 2585, 5025.
		793604 Spring-Governor Used on Type No(s). 0121, 0145, 0155, 2121, 2145.
216	**793494**	Link-Choke
217	**797864**	Spring-Choke Return
217B	**592484**	Spring-Choke Return
219	**793512**	Gear-Governor
222	**793487**	Bracket-Control
227	**793516**	Lever-Governor Control
236	**796161**	Link-Lockout Used on Type No(s). 0177, 0178, 2133, 2134, 3133, 5025.
		------ Note ------
		796161 Link-Lockout (Used After Code Date 08061500). Used on Type No(s). 2015, 2025.
		691826 Link-Lockout Used on Type No(s). 0015, 0025, 0133, 0134.
		691826 Link-Lockout (Used Before Code Date 08061600). Used on Type No(s). 2015, 2025.
238	**793535**	Cap-Valve
258	**699481**	Screw (Control Guard Bracket)
265	**691024**	Clamp-Casing
265A	**690798**	Clamp-Casing
267	**691044**	Screw (Casing Clamp)
276	**793627**	Washer-Sealing
276B	**592489**	Washer-Sealing
291	**793498**	Thermostat
300	**793468**	Muffler Used on Type No(s). 0100.
300A	**793496**	Muffler
300B	**793679**	Muffler Used on Type No(s). 0112, 0115, 0116, 0118, 0120, 0129, 0131, 0137, 0152, 0153, 0154, 0157, 0160, 0161, 0164, 0165, 0167, 0170, 0171, 0173, 0174, 0186, 0584, 0585, 0684, 0685, 0718, 2112, 2115, 2116, 2118, 2120, 2129, 2131, 2136, 2137, 2584, 2585, 3112, 3116, 3129, 3137, 3152, 3153, 3154, 3157, 3160, 3161, 3164, 3165, 3167, 3170, 3684, 3685.
304	**793486**	Housing-Blower (Rewind Start)
		------- Note -----
		794105 Housing-Blower (Electric Start)
309	**796386**	Motor-Starter
332	**690662**	Nut (Flywheel) (SAE)
332A	**792723**	Nut (Flywheel) (Metric)
333	**793449**	Armature-Magneto
334	**793454**	Screw (Magneto Armature)
337	**692720**	Plug-Spark
		------- Note -----
		692051 Plug-Spark Used on Type No(s). 0015, 0100, 0121, 0155, 0584, 0585, 0718, 2015, 2121, 2584, 2585.
356	**692390**	Wire-Stop
358	**793623**	Gasket Set-Engine
363	**19069**	Puller-Flywheel
365	**793458**	Screw (Carburetor)
371	**794574**	Gear-Cam
383	**19576s**	Wrench-Spark Plug
404	**690272**	Washer (Governor Crank)
423	**592511**	Stud (Control Guard Bracket)
425	**793460**	Screw (Air Cleaner Cover)
445	**792038**	Filter-Air Cleaner Cartridge
474	**794103**	Alternator
505	**793515**	Nut (Governor Control Lever)
513	**795100**	Clutch-Drive
523	**793475**	Dipstick
524	**793476**	Seal-Dipstick Tube
525	**793477**	Tube-Dipstick
535	**793676**	Filter-Air Cleaner Foam
562	**793514**	Bolt (Governor Control Lever)
578	**398153**	Wire Assembly Used on Type No(s). 0015, 0025, 0133, 0134, 0177, 0178, 2015, 2025, 2129, 2133, 2134, 3133, 5025.
578A	**794104**	Wire Assembly Used on Type No(s). 0116, 0120, 0152, 0154, 0165, 0167, 0171, 2116, 2120, 2136, 3116, 3152, 3154, 3165, 3167.
578B	**796980**	Wire Assembly Used on Type No(s). 0174, 0584, 0685, 0718, 2584, 3685.
592	**793481**	Nut (Rewind Starter)
598	**592587**	Shim-End Play
601	**791850**	Hose-Clamp
608	**793470**	Starter-Rewind (Standard Grip)
608A	**798909**	Starter-Rewind (Ergonomic Grip)

Not for Reproduction

100600

REF. NO.	PART NO.	DESCRIPTION
613	**793469**	Screw (Muffler)
613A	**793495**	Screw (Muffler)
613B	**793680**	Screw (Muffler)
615	**690340**	Retainer-Governor Shaft
616	**793448**	Crank-Governor
621	**692310**	Switch-Stop
623	**793628**	Seal-O Ring (Carburetor Spacer)
635	**66538s**	Boot-Spark Plug
660	**592446**	Bracket-Control Guard
662	**793478**	Stud (Rewind Starter)
662A	**793479**	Stud (Rewind Starter)
670	**793485**	Spacer-Fuel Tank
718	**690959**	Pin-Locating (Cylinder)
741	**793446**	Gear-Timing
742	**795094**	Retainer-E Ring (Used After Code Date 08123100).
		------ Note ------
		93941 Retainer-E Ring (Used Before Code Date 09010100).
745	**793491**	Screw (Brake)
783	**795099**	Gear-Pinion
783A	**795096**	Gear-Pinion
787	**793513**	Arm-Lever
793	**793511**	Screw/Nut Set (Lever Arm)
832	**793499**	Guard-Muffler
832B	**793681**	Guard-Muffler Used on Type No(s). 0112, 0115, 0116, 0118, 0120, 0129, 0131, 0137, 0152, 0153, 0154, 0157, 0160, 0161, 0164, 0165, 0167, 0170, 0171, 0173, 0174, 0186, 0584, 0585, 0684, 0685, 0718, 2112, 2115, 2116, 2118, 2120, 2129, 2131, 2136, 2137, 2584, 2585, 3112, 3116, 3129, 3137, 3152, 3153, 3154, 3157, 3160, 3161, 3164, 3165, 3167, 3170, 3684, 3685.
836	**793500**	Screw (Muffler Guard)
842	**691031**	Seal-O Ring (Dipstick)
843	**691884**	Sleeve-Lever
847	**793474**	Diptstick/Tube Assembly
851	**493880s**	Terminal-Spark Plug
857	**793533**	Trim-Blower Housing Cover
868	**793507**	Seal-Valve
875	**793462**	Base-Air Cleaner
875A		Base-Air Cleaner (No Longer Available) (For Replacement, Order Reference 875)
883	**793497**	Gasket-Exhaust
910	**794101**	Stud (Alternator)
914	**794451**	Screw (Rocker Cover)
921	**793531**	Cover-Blower Housing
922	**692135**	Spring-Brake
923	**796635**	Brake
		------ Note ------
		793490 Brake (No Longer Available) Used on Type No(s). 0015, 0025 0100, 0110, 0111, 0112, 0115, 0119, 0121, 0122, 0123, 0124, 0126, 0128, 0130, 0131, 0133, 0134, 0137, 0138, 0139, 0144, 0145, 0550, 0585, 0771, 0980, 0983, 1144.
		794107 Brake Used on Type No(s). 0116, 0120, 0584.
925	**793678**	Cover-Linkage Used on Type No(s). 0118, 0129, 0150, 0158, 0161, 0186, 0187, 2118, 2129, 2147, 2148, 3129, 3147, 3148, 3161.
925A	**796979**	Cover-Linkage Used on Type No(s). 0165, 0174, 0584, 0685, 0718, 2584.
937	**798330**	Spline-Starter

Not for Reproduction

REF. NO.	PART NO.	DESCRIPTION
942	**793673**	Bracket-Brake
950	**793465**	Screw-Float Bowl
950B	**592488**	Screw-Float Bowl
955B	**592493**	Plug-Carburetor
957	**692046**	Cap-Fuel Tank (Standard)
957A	**796577**	Cap-Fuel Tank (Tethered)
958	**698183**	Valve-Fuel Shut Off (Plastic)
968	**793428**	Cover-Air Cleaner Used on Type No(s). 0015, 0025, 0100, 0121, 0122, 0145, 0155, 0187, 0550, 0584, 0585, 0718, 1144, 1442, 2015, 2025, 2121, 2122, 2144, 2145, 2550, 2584, 2585, 5025.
968A	**793432**	Cover-Air Cleaner Used on Type No(s). 0110, 0118, 0131, 0160, 0161, 2110, 2118, 2131, 3160, 3161.
968B	**793532**	Cover-Air Cleaner
969	**690700**	Screw (Blower Housing Cover)
971	**793459**	Screw (Air Cleaner Base To Carburetor)
972	**793472**	Tank-Fuel (Standard Cap)
972A	**799291**	Tank-Fuel (Tethered Cap)
975	**793464**	Bowl-Float
975B	**592492**	Bowl-Float
976	**694395**	Primer-Carburetor Used on Type No(s). 0100.
1009	**794099**	Screw (Starter Motor)
1022	**793437**	Gasket-Rocker Cover
1023	**793436**	Cover-Rocker
1036		Label-Emissions (Available From A Briggs & Stratton Authorized Dealer)
1058	**277099**	Operator's Manual
1059	**793471**	Kit-Screw/Washer (Fuel Tank)
1095	**793624**	Gasket Set-Valve
1119	**794100**	Screw (Alternator)
1208	**699776**	Screw (Brake Bracket)
1263	**697124**	Reed-Breather
1264	**793453**	Screw (Breather Reed)
1319	**794467**	Label-Warning
1319A	**797669**	Label-Warning
1330	**277527**	Manual-Repair
1375	**793442**	Cover-Breather/Reed
1376	**699851**	Screw (Breather/Reed Cover)

Not for Reproduction

Not for
Reproduction