



Item No.	Part No.	Description	QTY
1	34103651	Handle	1
2	3220186	Screw	2
3	34103645	Decoration cover	1
4	31301645-1	Housing assembly	1
5	34104645	Decoration cover	1
6	31302645-1	Handle assembly	1
7	36301454-2	Micro switch	2
8	34101994	Housing battery socket	1
9	34114976	Battery	1
10	34107645	Switch trigger	1
11	32201651	Spring	3
12	36204213-2	PCB board	1
13	34109453-2	Lock-off button	1
14	34102645	Rotating button	1
15	34102651	Front handle	1
16	34101651	Rear handle	1
17	32201459	Screw	22
18	34101645	Guard shield	1
19	32201675A	Screw	2
20	33101883-6	Blade assembly	1
21	34107647	Plate	1
22	36101645	Motor	1
23	34111459-1	Gear box	1
24	33203453	Bearing	1
25	33301453	Washer	1
26	33302453	Washer	1
27	34105645	Decoration cover	1
28	33202451	Gear	1
29	33200451	Gear	1
30	33203161	Pin	2
31	33201451-1	Gear	1
32	33305453	Plate	1
33	33306453	Washer	1
34	33202453	Sleeve	1
35	33303453	Gear box cover	1
36	33902459	Sleeve	1
37	34106645	Decoration cover	1
38	33203505-1	Screw	2
39	36102583	Magnetic ring	1
40	36901645	Inductor	1
41	33304453-1	Eccentric block	2
42	33402708	Spring	2