



551Q新绞龙

ZLST551Q零配件明细表 Spare part list

编号	Code 代号	名 称	English Name	数量
1	SJ-042	SJ扶手套件	SJ Handrail kit	1套
2	SB-001	防松螺母	Lock nut	2
3	SJ-110	SJ手柄	SJ Handle	2
4	SJ-047	SJ橡胶帽	SJ Rubber Cap	2
5	SB-002	外六角螺丝	Hexagonal Screw	2
7	SB-118	平垫	Plain cushion	1
8	SJ-032B	SJ铁杆	SJ Iron Stick	2
9	SB-004	铜螺母	Nut	2
10	SJ-032	SJ铁丝杆1	SJ Iron Stick 1	1套
11	SB-123	卡簧	Retailing Circlip	1
12	SB-165	油封	Oil Seal	2
13	SB-006	防松螺母	Lock nut	1
14	SJ-033	SJ铁丝杆2	SJ Iron Stick 2	1套
15	SB-007	六角螺母	Hexagonal Nut	1
16	SJ-044B	SJ转杆	SJ Crank	1
17	SJ-044C	SJ转杆橡胶圈	SJ Rubber Circle	1
18	SJ-068A	SJ操纵杆	SJ joystick	1
19	SB-008	法兰螺母	Flange nut	2
20	SB-009	内六角螺丝	Hexagonal Screw	2
21	SB-010	法兰螺母	Flange nut	1
22	SB-011	外六角螺丝	Hexagonal Screw	1
23	SJ-068B	SJ操纵杆钢片	SJ joystick plate	1
24	SB-012	外六角螺丝	Hexagonal Screw	1
25	SB-013	防松螺母	Lock nut	4
26	SB-014	外六角螺丝	Hexagonal Screw	4
27	SJ-109	SJ限位框	SJ Limit frame	1
28	SB-015	外六角螺丝	Hexagonal Screw	2
29	SJ-028	SJ扶手杆垫片	SJ Handle Washer	2
30	SB-016	平垫	Plain cushion	2
31	SB-017	外六角螺丝	Hexagonal Screw	2
32	SJ-026	SJ端盖轴套	SJ head shaft sleeve	2
33	SJ-003	SJ大齿轮	SJ Gear	1
34	SB-018	半圆键	Semicircular key	2
35	SB-019	销子	Pin	1
36	SJ-017	SJ驱动轮轴	SJ Drive Bearing	1
37	SJ-066	SJ弹簧销	SJ Spring Pin	2
38	SB-020	平垫	Plain cushion	3
39	SB-021	轮胎	Tyre	2
40	SJ-134	汽油机	Gasoline Engine	1
41	SB-022	外六角螺丝	Hexagonal Screw	2
42	SB-023	平垫	Plain cushion	2

43	SJ-031	SJ皮带轮罩壳	SJ Pulley Cover	1
44	SB-024	防松螺母	Lock nut	4
45	SB-025	平垫	Plain cushion	4
46	SJ-052	外六角螺丝	Hexagonal Screw	2
47	SJ-016B	SJ拉线滑轮	SJ wire pulley	1
48	SJ-016A	SJ滑轮安装板1	SJ pulley sub panel 1	1
49	SB-026	平垫	Plain cushion	2
50	SB-027	外六角螺丝	Hexagonal Screw	2
51	SB-028	防松螺母	Lock nut	2
52	SJ-014	SJ滑轮安装板3	SJ pulley sub panel 3	1
53	SJ-016B	SJ拉线滑轮	SJ wire pulley	1
54	SB-029	外六角螺丝	Hexagonal Screw	2
55	SB-030	平垫	Plain cushion	2
56	SB-031	防松螺母	Lock nut	6
57	SB-032	平垫	Plain cushion	6
58	SJ-103	SJ传动箱罩壳	SJ Gearbox Cover	1
59	SB-033	外六角螺丝	Hexagonal Screw	4
60	SB-034	外六角螺丝	Hexagonal Screw	1
61	SB-035	外六角螺丝	Hexagonal Screw	1
62	SB-036	防松螺母	Lock nut	3
63	SB-037	十字槽半圆头螺丝	Hexagonal Screw	1
64	SB-038	平垫	Plain cushion	1
65	SJ-018	SJ手摇套	SJ Handle Sleeve	1
66	SB-039	外六角螺丝	Hexagonal Screw	2
67	SB-040	平垫	Plain cushion	1
68	SJ-102	SJ传动箱罩板	SJ Gearbox Cover	1
69	SB-041	平垫	Plain cushion	4
70	SB-042	外六角螺丝	Hexagonal Screw	4
71	SB-043	防松螺母	Lock nut	1
72	SJ-045	SJ小张紧板	SJ Tension Plate	1
73	SJ-046-1	小张紧板凸垫	Tension convex washer	1
74	SB-044	外六角螺丝	Hexagonal Screw	1
75	SJ-035-1	SJ弹簧3	SJ Spring 3	1
76	SX-11-170B	小张紧轮凸垫	SJ Washer 2	1
77	SB-045	外六角螺丝	Hexagonal Screw	1
78	SB-046	平垫	Plain cushion	2
79	SX-11-170	小张紧轮(加轴承)	SJ Tension pulley (+Bearing)	1套
80	SJ-008C	垫衬	SJ Pallet	1
81	SB-047	外六角螺丝	Hexagonal Screw	1
82	SJ-049	SJ主同步轮	Man Synchronization Wheel	1
83	SB-048	平垫	Plain cushion	1
84	SB-049	外六角法兰螺丝	Hexagonal Screw	1
85	SJ-049B	SJ主皮带轮	SJ Main pulley	1
86	SB-050	三角皮带	V-belt	1
87	SB-051	同步带	Synchronization Belt	1

88	SB-052	六角螺丝	Hexagonal Screw	1
89	SB-053	平垫	Plain cushion	3
90	SB-054	带止动槽深沟球轴承	Deep groove bearing with snap ring	1
92	SJ-005	SJ六角变速轴	SJ Hexagon Gear-shaft	1
93	SJ-013C	SJ变速轮	SJ Change pulley	
94	SB-055	外六角螺丝	Hexagonal Screw	
95	SJ-013D	SJ变速轮橡胶圈	SJ change wheel rubber ring	
96	SJ-013A	SJ变速轮大垫圈	SJ Change pulley washer	
97	SB-056	外六角螺丝	Hexagonal Screw	
98	SJ-013B	SJ变速轮轴盖	SJ Change pulley cover	
99	SB-057	轴用卡簧	Snap Spring	
100	SB-058	深沟球轴承	Deep slot bearing	
101	SB-059	平垫	Plain cushion	
102	SB-060	螺母	nut	
103	SJ-002	SJ直角铁块	SJ Orthogonal Iron	
104	SB-061	外六角螺丝	Hexagonal Screw	
105	SJ-040	SJ拨叉	SJ Gear lever	
106	SJ-010A	SJ传动同步轮	Drive Synchronization Wheel	
107	SJ-010B	SJ传动皮带轮轴	SJ Driving belt axle	
108	SB-062	深沟球轴承	Deep slot bearing	
109	SJ-007	SJ皮带轮支架	SJ Pulley bracket	
110	SB-063	销子	Pin	
111	SB-064	防松螺母	Lock nut	
112	SJ-069	弹簧6	Spring 6	
113	SJ-107	SJ隔套	SJ Separate Sleeve	
114	SB-065	平垫	Plain cushion	
115	SB-066	法兰螺母	Lock nut	
116	SJ-015	SJ滑轮安装板2	SJ Pulley sub panel 2	
117	SB-067	平垫	Plain cushion	
118	SB-068	外六角螺丝	Hexagonal Screw	
119	SJ-016B	SJ拉线滑轮	SJ wire pulley	
120	SJ-052	外六角螺丝	Hexagonal Screw	
121	SJ-008	SJ大张紧轮2(加轴承)	SJ Tension pulley 2(+Bearing)	
122	SJ-008B	SJ垫套	SJ Washer	
123	SB-069	外六角螺丝	Hexagonal Screw	
124	SJ-008C	SJ垫衬	SJ Pallet	
125	SB-070	防松螺母	Lock nut	
126	SB-071	防松螺母	Lock nut	
127	SB-072	平垫	Plain cushion	
128	SJ-023	SJ固定板	SJ Dead plate	
129	SJ-032A	SJ弹簧1	Spring 1	
130	SJ-050	SJ六角螺丝1	SJ Hexangular Screw 1	
131	SJ-037	弹簧5	Spring 5	
132	SB-073	平垫	Plain cushion	

133	SB-074	防松螺母	Lock nut
134	SB-075	外六角螺丝	Hexagonal Screw
135	SB-076	平垫	Plain cushion
136	SJ-039	SJ大皮带轮	SJ Pulley
137	SB-077	防松螺母	Lock nut
138	SJ-004	SJ圆底盖	SJ Rockered Cover
139	SB-078	方键	Square Key
140	SB-079	带座外球面球轴承	Bearing
141	SJ-044A	SJ摇杆	SJ Rocker Handle
142	SJ-011A	SJ安装板塑料圈	SJ sub panel plastic circle
143	SB-080	销子	Pin
144	SB-081	半园头方颈螺丝	Step bolt
145	SJ-011	SJ小安装板	SJ Sub panel
146	SB-082	防松螺母	Lock nut
147	SB-083	平垫	Plain cushion
148	SB-084	防松螺母	Lock nut
149	SB-085	半园头方颈螺丝	Step bolt
150	SB-086	防松螺母	Lock nut
151	SJ-006	SJ长挡板	SJ Shave Plate
152	SB-087	半园头方颈螺丝	Step bolt
153	SB-088	平垫	Plain cushion
154	SB-089	防松螺母	Lock nut
155	SB-090	平垫	Plain cushion
156	SJ-111	SJ滑撬	SJ Sliding Stick
157	SJ-104	SJ大罩壳	SJ Steel Cover
158	SJ-022	SJ输出轴	SJ Output Shaft
159	SB-091	半圆键	Semicircular key
160	SB-092	防松螺母	Lock nut
161	SJ-070	非标螺丝	Not-Standard Screw
162	SJ-067A	SJ左搅龙	SJ Left Auger
163	SJ-019	SJ驱动轴小套	SJ Drive Shaft Sheath
164	SB-093	平垫	Plain cushion
165	SJ-020	SJ轴套	SJ Shaft Sheath
166	SJ-024	SJ轴承盖	SJ Bearing Cover
167	SB-094	平垫	Plain cushion
168	SB-095	外六角螺丝	Hexagonal Screw
169	SJ-067	SJ右搅龙	SJ Right Auger
170	SB-096	六角螺丝	Hexangular Screw
171	SB-097	弹簧垫圈	Spring Washer
172	SB-098	平垫	Plain cushion
173	SJ-038	SJ蜗轮	SJ Worm Wheel
174	SJ-101	SJ上底座	SJ Upper Pedestal
175	SJ-108	SJ输出轴套	SJ Shaft Sheath
176	SJ-019	SJ驱动轴小套	SJ Drive Shaft Sheath
177	SJ-101A	SJ底座	SJ Pedestal

178	SB-099	深沟球轴承	Deep slot bearing	
179	SJ-030	SJ传动蜗轮轴	SJ Drive Worm shaft	
180	SB-100	深沟球轴承	Deep slot bearing	
181	SB-101	单向推力球轴承	One direction thrust bearing	
182	SB-102	油封	Oil Seal	
183	SB-103	销子	Pin	
184	SJ-057	隔圈	Washer	
185	SJ-001	SJ风扇	SJ Fan	
186	SB-104	半园头方颈螺丝	Step bolt	
187	SB-105	平垫	Plain cushion	
188	SB-106	防松螺母	Lock nut	
189	SB-107	防松螺母	Lock nut	
190	SB-108	外六角螺丝	Hexagonal Screw	
191	SB-109	防松螺母	Lock nut	
192	SJ-021	出雪口压片	Chute Bead	
193	SJ-021C	出雪口垫片	Chute Gasket	
194	SB-120	外六角螺丝	Hexagonal Screw	
195	SB-111	防松螺母	Lock nut	
196	SJ-138	锁紧手柄	Locking Handle	
197	SB-112	半园头方颈螺丝	Step bolt	
198	SJ-140	出雪口	Discharge Chute	
199	SB-113	外六角螺丝	Hexagonal Screw	
200	SJ-036	弹簧4	Spring 4	
201	SB-114	法兰螺母	Lock nut	
202	SJ-012	SJ弯杆套件	SJ Discharge Chute Accessories	
203	SJ-150	塑料铲	Plastic Shovel	
204	SB-110	半园头方颈螺丝	Step bolt	
205	SJ-151	铲座	Shovel base	1
206	SJ-113	纸垫	Paper cushion	1
207	SB-115	六角螺丝	Hexagonal Screw	1
208	SB-121	法兰螺丝	Flange screw	2
209	SJ-130	隔热罩	Thermally insulated shroud	1
211	SB-117	波形垫片	Corrugated gasket	1
212	SB-116	加油嘴	Lubricating Oil Nipple	1
213	SB-119	一字螺栓	Bolt	1
214	SJ-122	电灯	Lamp	1
215	SB-160	外六角螺母	Hexagonal nut	1
216	SJ-123	灯架	Lamp bracket	1
217	SB-161	外六角螺栓	Hexagonal bolt	1
218	SB-162	外六角螺母	Hexagonal nut	1
219	SJ-120	电瓶盖	Battery cover	1
220	SB-163	外六角螺栓	Hexagonal bolt	1
221	SB-164	外六角螺母	Hexagonal nut	1
222	SJ-121	电瓶	Battery	1
223		塑料隔套	Plastic sleeve	

224		塑料隔套	Plastic sleeve	
-----	--	------	----------------	--